Field Calibration Procedures for Solid and Semi-Solid Animal Waste Application Equipment





North Carolina Cooperative Extension Service

North Carolina State University

Field Calibration Procedures for Solid and Semi-Solid Animal Waste Application Equipment

WEIGHT-AREA METHOD

SPREADER SYSTEM

Information presented in manufacturer's charts are based on average operating conditions for relatively new equipment. Discharge rates and application rates change over time as equipment gets older and components wear. For solid or semi-solid application equipment, application rates and patterns may vary depending on forward travel and/or PTO speed, gear box settings, gate openings, operating pressures, spread widths, and overlaps.

Equipment should be calibrated on a regular basis to ensure proper application rates and uniformity. Calibration is a simple procedure involving collecting and measuring the material being applied at several locations in the application area. Calibration helps ensure that nutrients from animal waste are applied efficiently and at proper rates.

Solid or semi-solid (slurry) applicators can be calibrated by one of two methods: **load-area method**, and **weight-area method**.

Load-Area Method

To use the load-area method, you must know the spreader capacity. Spreader capacity is normally rated by the manufacturer and often is indicated on the application equipment. Liquid spreaders are normally rated in gallons while semi-solid spreaders are rated in either bushels or cubic feet.

As the name implies, the load-area method involves applying a full load to a measured area. For ease of measurement, it is best to use a rectangular field pattern. For PTO-driven spreaders, application rate is dependent on ground speed so a uniform speed must be maintained throughout the swath length. Ground-driven applicators apply reasonably uniform rates independent of ground speed. Refer to fact sheet AG-553-5 for detailed calibration procedures.

Weight-Area Method

The weight-area method is often used for solid and semi-solid spreaders. The procedure involves measuring the spreader discharge over a small measured area. The application rate is determined by dividing the collected material (weight) by the collection area.

Weight-Area Method Calibration Procedure

1. Obtain a tarp or plastic sheet of about 100 square feet $(9' \times 12', 10' \times 10', 10' \times 12', \text{ etc.})$ and measure for exact surface area (length × width).

2. Weigh the tarp using a set of spring-tension or platform scales.

3. Spread the tarp and pin on the field surface at each corner with a tent stake or long nail through the eyelets.

4. Operate the spreader over the center of the tarp at the speed normally driven when applying manure on the field.

5. Make two additional passes on two opposite sides of the center of the tarp at the normal spreader overlap spacing.

6. Remove and fold the tarp being careful not to spill any collected material. Weigh the tarp and manure

WEIGHT-AREA METHOD SPREADER SYSTEM



Figure 1 (above). Proper spreader patterns necessary to achieve application uniformity.

(gross weight).

7. Subtract the empty tarp weight from the gross tarp plus manure weight to obtain the weight of manure applied.

8. Divide the amount of manure collected (pounds) by the tarp area (square feet) and multiply this value by 21.8 (43,560 ft²/ac divided by 2,000 lbs/ton) to convert pounds per square foot to tons per acre.

9. If the application rate needs to be adjusted, make the necessary changes (spreader settings, speed, or both) and repeat the procedure until the desired application rate is obtained.

Spreader Pattern Uniformity

Determination of spreader uniformity is an important component of spreader calibration. The pattern shape and uniformity determines the overlap required for uniform application. One of the pattern shapes shown in Figure 1 is required for a uniform





application.

To determine the uniformity of spread and the amount of overlap needed:

1. Place a line of small pans or trays equally spaced (2 to 4 feet apart) across the spreader path (See Figure 2). Label the pans chronologically as left or right from the center pan. Center pans may need to be shifted slightly out of the spreader wheel tracks. (Pans should be a minimum of 12 by 12 inches, no more than 24 by 24 inches, and 2 to 4 inches deep.)

2. Make one spreader pass directly over the center pan at normal operating speed and spreader settings.

— spinner PTO speed,

Record

- flow divider delivery point onto the spinners, and
- the spreader gate setting.
- 3. Weigh and record the contents caught in each pan.

4. The effective spread width is found by locating the pan on either side of the path center where the contents caught in the container is one-half the amount caught in the center pan.

5. The distance between the two pans on either side of the center (in Number 4) is the effective width. The outer fringes of the coverage area beyond these points should be overlapped on each subsequent

path Figure 2 (left). Position of catch pans to determine spreader pattern, swath width, and overlap of the spreader.

hould have at least 100 sq	uare feet (9'×12', '	10′ × 10′, etc.) (of surface area.		
a. width X I	ength	= area	ft²		
. Start applying manure de to the regular spread	ownrange of the ta	rp and spread ettings of the a	directly across the pplicator (speed, s	center of it in a preader settings,	manner simi overlap).
		Trial 1	Trial 2	Trial 3	
 b. Forward speed, gear, throttle setting 	or				
c. PTO speed or setting					
d. Spreader gate setting					
. Transfer the manure colle pin- tension or platform	ected on the tarp ir scales.	nto a weighing	container and we	gh using an accu	urate set of
e. Empty weight of weighing container					lbs
f. Gross weight of container + manure					lbs
g. Net weight of manure (f – e)					lbs
. Compute the manure ap	plication rate:				
h. Area or tarp (a)					ft ²
i. Application rate (g ÷ h)					lbs/ft ²
j. Application rate (i X	43560 ÷ 2000)				tons/acre
. Compute the nutrient ap	plication rate:				
k. Manure analysis	N				lbs/ton
	P ₂ O ₅				lbs/ton
	K ₂ O				lbs/ton
Application rate	N				lbs/acre
(j × k)	P ₂ O ₅				lbs/acre
	КO				lbs/acro

Prepared by

J.C. Barker, Biological and Agricultural Engineering Extension Specialist R.O. Evans, Biological and Agricultural Engineering Extension Specialist D.A. Crouse, Soil Science Extension Specialist

2,500 copies of this public document were printed at a cost of \$607, or \$.24 per copy.

Published by

NORTH CAROLINA COOPERATIVE EXTENSION SERVICE

Distributed in furtherance of the Acts of Congress of May 8 and June 30, 1914. Employment and program opportunities are offered to all people regardless of race, color, national origin, sex, age, or disability. North Carolina State University, North Carolina A&T State University, U.S. Department of Agriculture, and local governments cooperating.