

GEORGIA  
FARM\*A\*SYST



## IMPROVING DRINKING WATER WELL CONDITION

Anthony Tyson, Senior Public Service Associate,  
Biological & Agricultural Engineering

FARM ASSESSMENT SYSTEM

Cooperative Extension Service, The University of Georgia, College of Agricultural and Environmental Sciences, Athens

### PRE-ASSESSMENT:

#### Why Should I Be Concerned?

About 95 percent of Georgia's rural residents depend on *ground water*\* to supply their drinking water and farm needs. Wells are designed to provide clean water. If improperly constructed and maintained, bacteria, nitrates, pesticides, or petroleum products can contaminate *ground water*, putting family and livestock health at risk.

There are many documented cases of well contamination from farm activities near drinking water wells. The condition of your well and its proximity to contamination sources determine the risk it poses to the water you drink. For example, a cracked well *casing* can allow bacteria, nitrates, oil, and pesticides to enter more easily. A spill of fertilizers or pesticides mixed and loaded near the well can cause contamination. Feedlots, fertilizer applications, animal yards, septic systems and waste storage areas could release nitrates and bacteria in amounts harmful to your well.

Preventing contamination of your well is very important. Once the *ground water* supplying your well is contaminated, it is very difficult and costly to clean. The only options may be to treat the water, drill a new well or obtain water from another source. A contaminated well can also affect your neighbors' wells, posing further health threats.

#### How Does This Assessment Help Protect Drinking Water and the Environment?

- This assessment allows you to evaluate the environmental soundness of your farm and operational practices relating to your drinking water well condition.
- You are encouraged to complete the entire document and use all eight areas when completing the assessment.
- The assessment asks a series of questions about your well condition and location.
- The assessment evaluation uses your answers (rankings) to identify practices or structures at risk and which should be modified to prevent pollution.
- The well condition facts provide an overview of sound environmental practices that can prevent pollution caused directly by well condition or location.
- You are encouraged to develop an action plan based on your needs as identified by the assessment. The well condition facts, reference and publication list provide alternatives to current practices as well as structural modifications that can prevent pollution on your farm.
- Farm\*A\*Syst is a voluntary program.
- The assessment should be conducted by you for your use. If needed, a professional from the Georgia Cooperative Extension Service or one of the other partnership organizations can provide assistance in completing the assessment or action plan.
- No information from this assessment needs to leave your farm.

\* Words found in italics are defined in the glossary.

# ASSESSMENT:

## Assessing Your Well Condition

For each category listed on the left, read across to the right and circle the statement that best describes conditions on your farm. If a category does not apply, for example: if it asks about the separation distance of your livestock facilities and you don't have any livestock, then skip the question. Once you have decided the most appropriate answer, look above that description to find your rank number (4, 3, 2 or 1) and enter that number in the "RANK" column. The entire assessment should take less than 30 minutes. A glossary on page 10 clarifies words found in italics throughout this assessment.

<b>DRINKING WATER WELL CONDITION</b>					
	<b>LOW RISK (rank 4)</b>	<b>LOW-MOD RISK (rank 3)</b>	<b>MOD-HIGH RISK (rank 2)</b>	<b>HIGH RISK (rank 1)</b>	<b>RANK</b>
<b>WELL LOCATION</b>					
<b>Position of drinking water well in relation to potential pollution sources</b>	Up slope from all pollution sources. No surface water runoff enters well. Surface water diverted from well.	Up slope from most pollution sources. No surface water runoff enters well.	Down slope from most pollution sources. Some surface water runoff may enter well.	Low area near <i>casing</i> . Surface water runoff from barnyard, pesticide mixing area, fuel storage, or farm dump enters well.	
<b>Separation distances between well and farm contamination sources (See Table 1)</b>	Meets or exceeds all state minimum required separation distances.	Meets most minimum separation distances.	Meets minimum separation distances only for sources required to be at least 100 feet from well.	<i>Does not meet all minimum separation distances for sources required to be at least 100 feet from well.**</i>	
<b>Soil and/or subsurface potential to protect ground water</b>	Fine-textured soils (clays or clay loams). Water table or limestone deeper than 20 feet.	Medium-textured soils (silt loam, loam). Water table or limestone deeper than 20 feet.	Medium- or coarse-textured soils (sands, sandy loams). Water table or limestone deeper than 20 feet.	Coarse-textured soils (sands, sandy loams). Water table or limestone shallower than 20 feet.	
<b>CONDITION</b>					
<b>Condition of casing and well cap (seal)</b>	No holes or cracks visible. <i>Cap (seal)</i> tightly secured. Screened vent.	No defects visible. <i>Well cap</i> vented but not screened.	No holes or cracks visible. <i>Cap (seal)</i> loose.	Holes or cracks visible. <i>Cap (seal)</i> loose, missing or can hear falling water in well.	
<b>Casing depth</b>	Cased more than 50 feet below water level in well.	Cased 31-50 feet below water level in well.	Cased 10-30 feet below water level in well.	Cased less than 10 feet below water level in well or no <i>casing</i> .	
<b>Casing height above land surface</b>	More than 12 inches above grade.	8-12 inches above grade.	At grade or up to 8 inches above.	Below grade or in pit or basement.	

**\*\* These conditions are in violation of state and/or federal Law.**

## DRINKING WATER WELL CONDITION

	<b>LOW RISK (rank 4)</b>	<b>LOW-MOD RISK (rank 3)</b>	<b>MOD-HIGH RISK (rank 2)</b>	<b>HIGH RISK (rank 1)</b>	<b>RANK</b>
<b>Concrete Curbing</b>	Four inch thick concrete curbing extending at least 2 feet in all directions from well casing and sloping away from casing.	Four inch thick concrete curbing extending at least 2 feet in all directions. Curbing may contain cracks but no more than 1/2 inch wide.	Four inch thick concrete curbing extends less than 2 feet in some directions. Curbing may contain cracks wider than 1/2 inch and/or water channeling under curbing.	No concrete curbing around well casing.	
<b>Well age</b>	Less than 20 years old.	21-50 years old.	51-70 years old.	More than 70 years old.	
<b>Well type</b>	-----	Drilled.	Driven-point (sand point) or bored.	Dug well.	

### MANAGEMENT

<b>Backflow prevention</b>	<i>Anti-siphon devices installed on all faucets with hose connections. No cross connections between water supplies.</i>	<i>Anti-siphon devices installed on some faucets with hose connections.</i>	<i>No anti-siphon devices. Air gap maintained.**</i>	<i>No anti-siphon devices or air gap not maintained or cross connections between water supplies.**</i>	
<b>Unused well</b>	No unused, unsealed wells on farm.	Unused wells capped and protected.	Unused well on farm. Not capped or protected.	Unused well within 1000 feet of water well. Not capped or protected.	
<b>Water testing</b>	Consistent satisfactory quality. Bacteria, nitrate, and other tests meet standards.	Bacteria, nitrate or other tests occasionally below standards.	Bacteria, nitrate or other tests rarely meet standards.	No water tests done. Water discolored after rainstorms. Noticeable changes in color, clarity, odor or taste.	
<b>Maintenance</b>	Well is inspected regularly. Leaks are immediately repaired.	Wells are inspected occasionally. Leaks are repaired when needed.	Well is not regularly inspected. Only large leaks are repaired.	Well or piping is leaking.	

**\*\* These conditions are in violation of state and/or federal law.**

**Number of Areas Ranked** \_\_\_\_\_  
(Number of questions answered. There are a total of 13 questions.)

**Ranking Total** \_\_\_\_\_  
(Sum of all numbers in the "RANK" Column)

# ASSESSMENT EVALUATION:

## What Do I Do with These Rankings?

### STEP 1: Identify Areas Determined to Be at Risk

Low risk practices (4s) are ideal and should be your goal. Low to moderate risk practices (3s) provide reasonable protection. Moderate to high risk practices (2s) provide inadequate protection in many circumstances. High risk practices (1s) are inadequate and pose a high risk for causing environmental, health, economic, or regulatory problems.

**High risk practices, rankings of "1" require immediate attention.** Some may only require little effort to correct, while others could be major time commitments or costly to modify and may require planning or prioritizing before you take action. All activities identified as "high risk" or "1s" should be listed in the action plan. Rankings of "2s" should be examined in greater detail to determine the exact level of risk and attention given accordingly.

### STEP 2: Determine Your Well Risk Ranking

The Well Risk Ranking provides a general idea of how your well condition and farm practices might be affecting your ground and surface water or contaminating your soil.

Use the rankings total and the total number of areas ranked on page 3 to determine the Well Risk Ranking.

<b>RANKINGS TOTAL ÷ TOTAL NUMBER OF AREAS RANKED = WELL RISK RANKING</b>
_____ ÷ _____ = _____

WELL RISK RANKING .....	LEVEL OF RISK
3.6 to 4 .....	Low Risk
2.6 to 3.5 .....	Low to Moderate Risk
1.6 to 2.5 .....	Moderate Risk
1.0 to 1.5 .....	High Risk

This ranking gives you an idea of how your well condition and location might be affecting your drinking water. This ranking should serve only as a very general guide, and not as a precise diagnosis since it represents the average of many individual rankings.

### STEP 3: Read the Information/Fact Section on Improving Your Well Condition and Farm Practices

When reading, think about how you could modify your practices to address some of your moderate and high risk areas. If you have any questions that are not addressed in the well condition facts portion of this assessment, consult the references on page 12 or contact your county Extension agent for more information.

### STEP 4: Transfer Information to the Total Farm Assessment

If you are completing this assessment as part of a "Total Farm Assessment," also transfer your well risk ranking and your identified high risk practices to the overall farm assessment.

# WELL CONDITION FACTS:

## Improving Drinking Water Well Condition

### WELL LOCATION

Well location is very important in avoiding drinking water contamination. A well's location is crucial whether it taps water from just below the ground surface or from several hundred feet deep. It takes careful planning and consideration of the flow of surface water and *ground water* to locate a well in a safe place. A well downhill from a livestock yard, a leaking fuel tank or a failing septic system is at greater risk of contamination than a well located uphill from pollution sources.

Surface slope does not always indicate the direction a pollutant might flow once it gets into the ground. In shallow *aquifers*, *ground water* flow is often in the same direction as surface water flow. If the *aquifer* supplying water to your farm well is deep below the surface, its surface slope may not be an accurate indicator of *ground water* flow direction. Finding out about *ground water* movement on your farm may require special monitoring equipment (see Contacts and References).

### Separation Distance

Minimum separation distances from potential pollution sources aid in good well location and uses the soil as natural protection. In sandy soils with low organic content, these separation distances may not offer adequate protection. State well codes may not mention all farm activities and structures. For example, in Georgia, The Water Well Standards Act of 1985 does not specifically acknowledge such potential pollution sources as pesticide mixing, pesticide and fertilizer application, vehicle maintenance and farm waste-disposal areas. For animal husbandry operations, the only specified requirement is that the well shall be not less than 100 feet from an animal or fowl enclosure. Other required setbacks are listed in **Table 1**.

Greater setback distances may be required based on hydrogeology and soil type. When no distances are specified, provide as much separation as possible between your well and any potential contamination source. This is especially important if your farm is on highly permeable soils or thin soil overlying limestone *bedrock*, or if the contamination source or activity presents high risk.

Minimum separation distances are regulated for new well installation. Existing wells are required by law only to meet separation requirements effective at the time of well construction.

Both soil and slope can make siting a well a tricky business. Keep in mind that separation distances required by the state are minimums. You may want to choose greater separation distances

depending on factors at your site. This and proper well construction help provide reasonable assurance that your well will not be polluted by farm activities in the near future. Also consider contamination sources on adjacent properties.

Changing the location of your well in relation to contamination sources may protect your water supply, but not the *ground water* itself. Any condition likely to cause *ground water* contamination should be addressed, even if your well is far away from the potential source. *Ground water* contamination is a violation of Georgia law, even if drinking water is not immediately affected.

Simply separating your well from a contamination source may reduce the chance of pollution, but it does not guarantee that the well will be safe. Storm water and *ground water* can carry bacteria, nitrates, oil products, pesticides and other contaminants from one place to another. Wells located in the path of polluted water may be contaminated by surface water washing into an improperly-sealed well. Although less likely, some wells may become contaminated through polluted recharge at great distances, depending on the depth of the *aquifer* and the well intake.

**Table 1: Minimum Separation Distance Between Well and Potential Farm Sources of Contamination**

Separation Distances Required by Georgia Water Well Standards Act of 1985	
Distance from well	
10 Feet	Sewer Line
50 Feet	Septic Tank
100 Feet	Septic Tank Absorption Field
150 Feet	Cesspool or Seepage Pit
100 Feet	Animal or Fowl Enclosure


  

Separation Distances Recommended for Other Farm Sources of Contamination	
Distance from well	
150 Feet	Waste Lagoon
150 Feet	Dead Animal Burial Pits
100 Feet	Pesticide Storage, Mixing & Loading Facilities
100 Feet	Fertilizer Storage
500 Feet	Petroleum Tanks

## WELL CONSTRUCTION

Poor well design can allow *ground water* contamination by surface water reaching the water table without filtering through soil. Wells located in pits, or constructed without *grout* or a cap, can allow surface water to carry bacteria, nitrates, pesticides, fertilizer, or oil products into the drinking-water supply. Proper well design and construction reduce pollution risk by sealing the well from anything that might enter it from the surface (See Figure 1).

**Figure 1: Typical Well Showing Proper Construction to Prevent Contamination**



The way in which a well is constructed, even when the design is sound, affects its ability to keep out contaminants. You should check the *casing* and cap, *casing* depth and height, well age, type and depth.

The following overview of well construction and inspection can help you understand your drinking water contamination risk ranking.

### Casing And Well Cap

The licensed water well contractor installs a steel or plastic pipe called *casing* during construction to prevent collapse of the borehole. Left unsealed, the space between the *casing* and the sides of the hole provide a direct channel for

surface water (and pollutants) to reach the water table. To seal off that channel, the licensed water well contractor fills the space with *grout* (i.e., cement, concrete or a special type of clay called bentonite, or a mixture of cement and water, depending on the geologic materials encountered). Both *grout* and *casing* prevent pollutants from seeping into the well.

Georgia law requires that, "a well having an open annular space between the *casing* and bore hole shall be grouted and shall be filled with neat or sand cement or other impervious materials to prevent the entrance of pollutants or contaminants." The minimum depth of seal for individual wells is 10 feet. It is preferred, however, that the well *grout* extend all the way from the ground surface to the water-bearing formation.

With a light you may be able to visually inspect your *well casing* for holes or cracks at the surface or down the inside of the *casing*. If you can move the *casing* around by pushing against it, you may have a problem with your well's ability to keep out contaminants. You can also check the *well casing* by listening for water running down into the well when the pump is not running. If you hear running water, there could be a crack or hole in the *casing*, or the well may not be cased down to the water level. Either situation is risky and reason not to drink the water until the situation is corrected.

To prevent contaminants from flowing into the top of the *well casing*, the licensed water well contractor installs a tight-fitting, tamper-resistant, vermin-proof well cap. This also prevents the entry of insects, small animals, or surface water. The cap should be firmly installed and include a screened vent so that air can enter the well. Vents should face the ground, be tightly connected to the *well cap or seal*, and be properly screened to keep insects out.

### Casing Height and Concrete Curbing

To prevent surface water contamination from entering the well, the upper terminal of the *well casing* should extend at least 12 inches above ground level. All Georgia wells located in areas subject to flooding shall have a *well casing* that extends at least 2 feet above the level of the highest known flood of record.

The Georgia Water Well Standards Act of 1985 also states that "All individual and non-public wells shall be curbed at the surface by the owner with a watertight curbing of concrete at least 4 inches thick and extending at least 2 feet in all directions from the *well casing* and sloping away from the *casing*."

## Well Age

Well age is an important factor in predicting the likelihood of contamination. A well constructed more than 70 years ago is likely to be at the center of the acreage, may be shallower and is probably surrounded by many potential contamination sources. Older well pumps are more likely to leak lubricating oils, which can get into the well. Older wells are also more likely to have thinner *casings*, which may be corroded through or improper *grouting*. Even wells with modern *casings* that are 30 to 40 years old are subject to corrosion and perforation. If you have an older well, you may want to have it inspected by a water well specialist or a licensed water well contractor.

## Well Type

- **Dug wells** - pose the highest risk of allowing contamination because they are shallow and often poorly protected from surface water. A *dug well* is a large diameter hole (usually more than 2 feet wide), which is often built by hand.
- **Bored wells** - are constructed using an earth auger, usually up to 2 feet in diameter. Concrete is the most common *casing* material. These wells are typically shallow (less than 60 feet) and thus tend to be susceptible to surface contamination. These wells pose a moderate to high risk of contamination.
- **Driven point (sand point) wells** - which pose a moderate to high risk, are constructed by driving assembled lengths of pipe into the ground. These wells are normally smaller in diameter (2 inches or less) and less than 50 feet deep. They can only be installed in relatively loose soils, such as sand.
- **Drilled wells** - cover all other types of wells, including those constructed by a combination of jetting and driving. *Drilled wells* for farm use are commonly 4 to 8 inches in diameter and when properly constructed pose a relatively low risk of contamination.

## Well Depth

Shallow wells draw from the *ground water* nearest the land surface, which may be directly affected by farm activities. Depending on how far the well *casing* extends below the water table, rain, surface water, and irrigation water soak into the soil and may carry pollutants with them.

Local geologic conditions determine how long it takes for well contamination to occur. In some

places, this process happens quickly (i.e., in weeks, days or even hours). Areas with thin soil over limestone or sand and gravel *aquifers* are particularly vulnerable. Even thick sands over limestone represent a site vulnerable to contamination.

On the other hand, thick clay soils retard the movement of contaminants. These soils prevent contamination, delay the day when a well "turns bad" or change the problem to runoff. If you have a deep well (more than several hundred feet below the water table), the *ground water* supplying your well may have traveled a considerable distance underground over a long time, offering greater protection to the well.

## MANAGING AND MAINTAINING EXISTING WELLS

Good maintenance means testing the water every year, keeping the well area clean and accessible, keeping pollutants as far away as possible, and periodically having a licensed water well contractor check the well's mechanics.

### Better Management of Your Existing Well

Existing wells were most likely located according to traditional practice or regulations in place at the time of construction. While these wells are still legal, you may want to consider the degree to which your well conforms to current drinking water standards. Current standards incorporate new knowledge about *ground water* contamination and well water.

You should move or upgrade activities such as pesticide mixing, tank rinsing, or fuel storage if they are within 100 feet of the well. You might want to upgrade wells, get rid of well pits, install *caps* or concrete curbing or extend *casings*. In Georgia, well repair and abandonment and new well construction require a licensed water well construction contractor.

Changing the location of other practices may prove difficult. (You can't move a livestock yard or a silo overnight.) Until you can drill a new well and plug the old one so that you meet minimum separation distance requirements, change the way you manage such structures to control contaminants. For instance, you could install concrete curbs to direct livestock yard runoff away from the well.

Short term manure stacks are another example. They pose a risk of well contamination by bacteria or nitrates. Locate them on clay soil or, better yet, a concrete slab to reduce the chance of polluting your drinking water. Also, protect them from rain which could promote leaching.

Other management changes you may want to consider include moving traffic areas and chemical

or gasoline storage areas away from the well and upgrading or better managing your septic system.

## Backflow Prevention

*Backflow*, or *back siphonage*, from pesticide mixing tanks allows chemicals to flow back into the well through a hose or pipe. Use an anti-siphon device when filling pesticide sprayer tanks to prevent the chemical mixture from flowing back into the well and contaminating *ground water*. Inexpensive anti-*backflow* devices for hoses to fill farm sprayers may be available from irrigation or spray equipment suppliers, but are not reliable protection. Maintain an *air gap* in systems where feasible. Keep the hose out of the tank when filling the pesticide sprayer.

A better alternative to filling spray tanks at the well is to use a nurse tank and mix and load pesticides in the field.

According to the Rules of Georgia Department of Agriculture, *Prevention of Ground and Surface Water Contamination*, Chapter 40-23-2, all irrigation systems designed or used to apply fertilizer or chemicals other than pesticides must be equipped with a *backflow* preventer consisting of a functional check valve, low pressure drain, and vacuum breaker. Certain pesticide labels may require additional safety precautions.

You should also consider anti-siphon devices on all faucets with hose connections or maintain *air gaps* between hoses or faucets and the water level. Otherwise, water from laundry tubs, sinks, washing machines, pressure washers, outside hydrants and swimming pools could flow back through plumbing to contaminate your water.

## Water Testing

Keep an eye on water quality in existing wells by testing them annually. Although you cannot have your water tested for every conceivable pollutant, some basic tests indicate whether other problems exist.

At a minimum, test your water annually for bacteria and nitrate. Testing once for corrosivity is also important. A good initial set of tests for a private well also includes hardness, pH, chloride, and other minerals such as iron and manganese.

The results may not include contaminants that could be near your farm, such as commonly-used pesticides in your area. Test for contaminants that are most likely at your farm. Test for lead if you have lead pipes or soldered copper joints. If possible, replace lead pipes. Test for *volatile organic chemicals (VOCs)* if there has been a nearby spill or storage of oil, petroleum or solvent. **While testing can be very expensive (often \$80-\$100 per compound analyzed for pesticides) the**

### expense may be justified if:

- Your well has nitrate levels over 10 mg/l (reported as nitrate-nitrogen, NO<sub>3</sub>-N).
- A pesticide spill has occurred near the well or *back siphonage* has occurred.
- Your well is shallow, has less than 15 feet of *casing* below the water table, or is located in sandy soil and down slope from irrigated croplands where pesticides are used.

Get further advice on appropriate tests to run from your county Extension office or health department.

### You should test your water more frequently if:

- There are unexplained illnesses in the family.
- There are pregnancies in the family.
- There are noticeable changes in livestock or poultry performance.
- Your neighbors find a particular contaminant in their water.
- You note a change in water taste, odor, color or clarity.
- You have a spill or *back siphonage* of chemicals or petroleum products near your well or on your farm.
- Your livestock operation inspectors require it.

You can have your water tested by public or private laboratories. Contact your county Extension office or health department for water testing information. Follow the lab's instructions for water sampling to ensure accuracy of results. Use only the container provided and return samples promptly. Bacteria sample bottles are sterile and must be returned within specified time limits.

Because many materials, including bacteria and nitrate-nitrogen, are naturally present in minor amounts in *ground water* or can vary seasonally, you may want to contact a specialist for help in interpreting test results.

Bacteria and nitrates are two important indicators of *ground water* contamination. At excessive levels, they can cause health problems by themselves and can suggest problems with the well's location or construction. Hardness and pH indicate how corrosive the water may be to your plumbing system. The chloride level indicates other problems. In coastal Georgia, chloride in wells may indicate saltwater intrusion into the *aquifer*.



Keep in mind that activities off your farm can affect your *ground water*. Chemical spills, changes in land use, and the presence of landfills can increase the chance of pollutants getting into your water. If your water has a high nitrate or bacteria level, you may want to talk with a specialist about the need for additional testing.

It is also important to record test results and note changes in water quality over time. In addition to water analysis test results, keep records of well construction details, and dates and results of well and pump maintenance to determine what's happening with your water.

## WELL MAINTENANCE

Well equipment doesn't last forever. Every 10 to 20 years, your well may require mechanical attention from a licensed well contractor. Follow these additional maintenance practices:

- Do not use gasoline or lawn and agricultural chemicals near your well.
- Do not mix pesticides, rinse sprayer equipment, or discard empty pesticide containers near your well.
- Protect wells from household wastewater treatment systems that may back up.
- Never store fuel, pesticides, empty containers, fertilizers or other potential pollutants near your well.

## New Wells

New wells are expensive, but they are a good investment for the future. Getting the most from such an investment means locating the well away from contamination sources and maintaining the quality of the well.

### Some simple principles:

- Follow the state-recommended minimum separation distances from potential contamination sources. **See Table 1.**
- Locate your well on ground higher than surrounding pollution sources such as fuel tanks, livestock yards, septic systems or pesticide mixing areas. **See Table 1.**
- Where practical, locate the well as far as possible from pollution sources, but no closer than the minimum separation distances listed above.

- If necessary, build up soil around the well so that all surface water drains away from it and install concrete curbing.
- Avoid areas that are prone to flooding or extend well *casing* at least 2 feet above the highest flood level of record.

Shallow *ground water* flow generally follows surface drainage patterns. Unless you know the exact direction of *ground water* flow on your property, locate the well so that pollution sources are between the well and the nearest creek, river or lake. *Ground water* generally flows from upland areas and discharges into a surface water body. In all cases, locate your well on ground higher than surrounding pollution sources such as fuel tanks, livestock yards or pesticide mixing areas.

- Make the well accessible for pump repair, cleaning, testing and inspection.
- Hire a licensed water well contractor. Make sure the contractor disinfects the well with chlorine after construction, tests the water for bacteria after drilling and gives you detailed information about the well's depth and construction.

## Unused Wells

Many farms in Georgia have old *abandoned wells* which are no longer in use. These wells represent a potential threat to other operating wells in the area because they can serve as a conduit for contaminants at the surface to enter the *aquifer*. Never use an *abandoned well* to dispose of garbage or any other material which could contaminate *ground water*.

The Water Well Standards Act of 1985 requires that all *abandoned wells* in the state must be "filled, sealed and plugged." In order to legally seal an *abandoned well*, the work must be performed by a licensed water well contractor.

## **GLOSSARY:**

### **Drinking Water Well Condition**

**Abandoned well:** A well that is no longer used or a well that has been permanently closed according to Georgia regulations.

**Air gap:** An air space (open space) between the hose or faucet and water level, representing one way to prevent *backflow* of liquids into a well or water supply.

**Anti-siphon device:** A safety device used to prevent *backflow* of a mixture of water and chemicals into the water supply.

**Aquifer:** A subsurface zone or strata of sand, gravel, or fractured rock that is used as a water source.

**Backflow:** The unwanted reverse flow of liquids in a piping system.

**Back siphonage:** *Backflow* caused by formation of a vacuum in a water supply pipe.

**Bedrock:** The solid rock that is under all soil, sand, clay, gravel and loose material on the earth's surface.

**Casing:** Steel or plastic pipe installed while drilling a well, to prevent collapse of the well bore hole and entrance of contaminants, and to allow placement of a pump or pumping equipment.

**Cross connection:** A link or channel between pipes, wells, fixtures, or tanks carrying contaminated water and those carrying potable (safe for drinking) water. Contaminated water, if at higher pressure, enters the potable water system.

**Drilled wells:** Wells not dug or driven, including those constructed by a combination of jetting or driving. These wells are normally 4 to 8 inches in diameter.

**Driven-point (sand point) wells:** Wells constructed by driving assembled lengths of pipe into the ground with percussion equipment or by hand. These wells are usually smaller in diameter (2 inches or less), less than 50 feet deep, and can be installed in areas of relatively loose soils and sediments, such as sand.

**Dug wells:** Large diameter wells often constructed by hand.

**Ground water:** Subsurface water in a zone of saturation.

**Grout:** Slurry of cement or clay used to seal the space between the outside of the *well casing* and the bore hole, or to seal an *abandoned well*.

**Milligrams per liter (mg/l):** The weight of a substance measured in milligrams contained in one liter. It is equivalent to 1 part per million in water measure.

**Parts per million (ppm):** A measurement of concentration of one unit of material dispersed in one million units of another.

**Water table:** The upper level of *ground water* in a zone of saturation. Fluctuates with climatic conditions on land surface, and with *aquifer* discharge and recharge rates.

**Well cap (seal):** A device used to cover the top of a *well casing* pipe.

**Volatile organic compounds (VOC):** Chemical release of vapors that escape into the air from certain activities, i.e. burning fuels or opening paint cans. These chemicals contribute to air quality problems and respiratory related illnesses.

## **ACTION PLAN:**

An action plan allows you to take the needed steps to modify the areas of concern as identified by your assessment. The outline below is a basic guide for developing an action plan. Feel free to expand your plan if you feel the need for detail or additional areas not included. Consult the list of references on the next page if additional assistance is needed.

<b>Area of Concern</b>	<b>Risk Ranking</b>	<b>Planned Action to Address Concern</b>	<b>Time Frame</b>	<b>Estimated Cost</b>

## REFERENCES:

<b>CONTACTS AND REFERENCES</b>			
<b>Organization</b>	<b>Responsibilities</b>	<b>Address</b>	<b>Phone number</b>
Georgia Department of Agriculture	Questions regarding anti-siphon requirements for irrigation systems.	Agriculture Bldg. 19 Martin Luther King Jr Dr. Atlanta, GA 30334	404-656-4958
Geologic Survey, Environmental Protection Division	Regulations concerning water well drinking standards.	Georgia DNR 19 Martin Luther King Jr. Dr., Suite 400 Atlanta, GA 30334	404-656-3214
Biological & Agricultural Engineering Department, University of Georgia	Questions related to well head protection or ground water on a farm.	Extension Unit Landrum Box 8112, GSU Statesboro, GA 30460	912-681-5653
Water Resource Management, Environmental Protection Division	Questions regarding public drinking water.	Georgia DNR 205 Butler St, SE, Floyd Towers East, Suite 1152 Atlanta, GA 30334	404-651-5168
Safe-Drinking Water Hotline U.S. Environmental Protection Agency	General drinking water questions. 8:30 a.m. - 5:00 p.m. EST.	401 M Street SW (Mail Code 4604) Washington D.C. 20460	800-426-4791
U.S. Environmental Protection Agency	General drinking water questions.	U.S. EPA Region IV 100 Alabama St. Atlanta, Georgia 30303	404-562-9424
Water Protection Branch, Environmental Protection Division	General water quality questions.	Georgia DNR 205 Butler St. SW, Suite 1058 East Floyde Tower Atlanta, GA 30334	404-651-5120 or 800-685-2443
Pollution Prevention Assistance Division	Pollution prevention references.	Georgia DNR 7 Martin Luther King Jr. Dr., Suite 450 Atlanta, GA 30334	404-651-5120 or 800-685-2443
Crop & Soil Sciences Department, University of Georgia	Questions related to the impact of farming practices on water quality.	Extension Water Quality Coordinator Plant Sciences Building Athens, GA 30602	706-542-9072

## **PUBLICATIONS:**

**Environmental Protection Agency (EPA)  
Information Center  
401 M Street SW, Washington, DC 20460**


- Drinking from Household Wells, EPA 570/9-90-013
- LEAD In Your Drinking Water, EPA 810-F-93-001
- Protecting Our Ground Water, EPA 813-F-95-002


**University of Georgia, Cooperative Extension Service  
Athens, Georgia 30602**

- Water Quality for Private Water Systems, Bulletin 939
- Water Quality Problems: Health and Household, Circular 819-A
- Your Drinking Water: Lead, Circular 819-4
- Wellhead Protection for Private Domestic Wells, Circular 819-12
- Wellhead Protection for Farm Wells, Circular 819-13
- Water Resource Management in Georgia, Bulletin 206
- Georgia's Ground Water Resources, Bulletin 1096
- Shock Chlorination of Home Wells, Springs and Cisterns, Miscellaneous Publication ENG93

**Northeast Regional Agricultural Engineering Service, Cooperative Extension  
152 Riley-Robb, Ithaca, NY 14853-5701**

- Home Water Treatment, NRAES-48. Includes water-treatment basics, physical and chemical treatments, USEPA Primary Drinking Water Standards and health advisories, and pesticide products that contain USEPA drinking-water contaminants. (120 pp.)





*The Georgia Farm Assessment System is a cooperative project  
of the Pollution Prevention Assistance Division, Georgia Department of Natural Resources,  
the University of Georgia, College of Agricultural and Environmental Sciences, Cooperative Extension Service,  
the Georgia Soil and Water Conservation Commission and the  
Georgia Natural Resources Conservation Service, USDA.*



This publication is an adaptation of the Florida Farm\*A\*Syst, Drinking Water Well Condition Fact Sheets and Work Sheets (revised from the Wisconsin and Minnesota prototype versions) authors, Virginia Peart, UF/IFAS Home Economics Dept.; Randall Brown and Jerry Sartain, UF/IFAS Soil and Water Science Dept.

The publication of this document was supported by The Pollution Prevention Assistance Division, Georgia Department of Natural Resources and was financed in part through a grant from the U.S. Environmental Protection Agency under provisions of section 319 of the Federal Water Pollution Control Act, as amended in 1987.

**GEORGIA FARM\*A\*SYST TEAM MEMBERS:**

Mark Risse, Ph.D., Public Service Assistant, Georgia Cooperative Extension Service/Pollution Prevention Assistance Division  
William Segars, Ph.D., Extension Agronomist & Water Quality Coordinator, Georgia Cooperative Extension Service  
Lisa Ann Kelley, Program Specialist, Farm\*A\*Syst Coordinator, Georgia Cooperative Extension Service/Pollution Prevention Assistance Division

**INTERAGENCY LEADERSHIP:**

G. Robert Kerr, Director, Pollution Prevention Assistance Division, Georgia Department of Natural Resources  
Dr. Gale Buchanan, Dean and Director, College of Agricultural & Environmental Sciences, University of Georgia  
F. Graham Liles Jr., Executive Director, State Soil & Water Conservation Commission  
Earl Cosby, State Conservationist, USDA, Natural Resources Conservation Service, United States Department of Agriculture

**TECHNICAL REVIEWERS :**

Alan Hallum & Sue Grunwald, EPD, Water Protection Branch; Brad Addison & Norton Johnson, EPD, Water Resources; Bruce O'Connor, Georgia Geological Survey; Jeffrey Jordan, Agricultural & Applied Economics, Georgia Experiment Station, UGA; Steven Woodruff, Gold Kist, Environmental Engineering & Compliance, William Segars, Water Quality Coordinator, Georgia Cooperative Extension Service and Larry Goff, Poultry Water Quality Consortium.

This document was also reviewed by Extension and Pollution Prevention review committees.

While the technical reviewers provided guidance in copy revisions and assisted in assuring accuracy of content, the views expressed in this publication are those of the author and do not necessarily reflect the views of the reviewers.

**LAYOUT, DESIGN AND TYPESETTING :**

EDITOR: Lisa Ann Kelley, Georgia Cooperative Extension Service/Pollution Prevention Assistance Division

GRAPHICS: Tina Fields, Carol Ness and Shannon O'Brien, Georgia Cooperative Extension Service

LOGO DESIGN: Jody Mayfield, Senior Artist, Georgia Department of Administrative Services

DESIGN REVIEW: Carol Nimmons, Georgia Cooperative Extension Service and Susan Williams, Florida Farm\*A\*Syst

The Pollution Prevention Assistance Division (P<sup>2</sup>AD) and all technical sources referenced in this assessment make no warranty or representation, expressed or implied, with respect to the information contained in this assessment. The use of any information, apparatus, method, or process mentioned in this assessment may not infringe upon privately owned rights. P<sup>2</sup>AD assumes no liability with respect to use of, or damages resulting from use of any information, apparatus, method, or process disclosed in this assessment. Mention of trade names of commercial products does not constitute endorsement or recommendation for use.

The University of Georgia and Ft. Valley State College, the U.S. Department of Agriculture and counties of the state cooperating. The Cooperative Extension Service offers educational programs, assistance and materials to all people without regard to race, color, national origin, age sex or disability. An equal opportunity/affirmative action organization committed to a diverse work force.

**Bulletin 1152-3**

**November 1996**

Issued in furtherance of Cooperative Extension work, Acts of May 8 and June 30, 1914, The University of Georgia College of Agricultural and Environmental Sciences and the U.S. Department of Agriculture cooperating.

Dr. Gale A. Buchanan, Dean and Director for Extension 97-67